Size:145x210mm



REMOTE CONTROL AIR COOLER MODEL: MY19RC



OPERATION & MAINTENANCE INSTRUCTIONS

Parts Diagram:

Please read this instruction manual carefully before use and keep in a safe place for future reference. If you give the appliance to another person, supply them with this instruction manual

General Information:


For best results, it is important to place the unit on the floor near an open window or door so that clean cool air is circulated at all times. Failure to do this can cause an odour due to the same air being re-circulated. to the same air being re-circulated.
If an odour is present, simply change the water and move the unit to an open window or door so fresh cool air is circulated at all times.

TECHNICAL DATA

Item number	MY19RC	
Power supply	220-240 V~ 50/60 Hz	
Power consumption	65 W	

- Children should not play with the appliance and if less than 3 years old, should be kept away unless continuously supervised.
- 3. Use as per the voltage rating label required.
- Do not repair or make mechanical alterations to the appliance. It should be repaired by a qualified person or returned to the distributor if faulty.
- If the supply power cable is damaged, it must be replaced by the manufacturer, its service agent or a similarly qualified person.

- Do not insert foreign objects into the air outlets and inlets. This could damage the unit and is dangerous.
- 10. Only use the appliance on a flat surface.
- 11. Do not use outdoors. 12. The level of water in the water tank should not go over the "MAX" indicator on the scale at any time. During operation, the total level of water in the water tank should not go below the "MIN" indicator on the scale at any time.
- After adding water to the water tank, do not tilt or knock over the appliance. The unit should remain stable on a flat surface once water is added to avoid spillage.
- 14. Do not turn the appliance over. If it is knocked over with water in the unit, turn off and unplug from the power supply immediately. The unit should then be checked by a qualified person or returned to your place of purchase for examination and repair.
- 16. Clean the unit with a light damp cloth and neutral deterg
- Do not place air outlets and/or inlets near to walls or curtains or any other constricting environment.
- Do not knock or shake the body of the unit when using. This may cause the appliance to stop automatically.
- To prevent odours from being emitted, change the water frequently and position the unit near an open window or door for better clean air circulation.



l Top water tank cover	7 Water inlet
2 Top water tank	8 Drain plag
3 Power cable tidy	9 Caster
4 Handle	10 Water tank
5 Protective screen	

results, it is important to place the unit on the floor near an open window or door cool air is circulated at all simes. Faiture to do this can cause an odour due to air being re-cliroutated.

It is present, simply change the water and move the unit to an open window or hat fresh cool air is circulated at all times.

- Assembling castors: Put the appliance on a flat surface and simply push the casters society into place.

 2. Tasks: Simply open the top Isl and put Got the white nubber bung and pour the water in from the top, remember to only fill to the mass level allown on the water indicator can the first of the surface. The water task, when the water task is full, remember to place the rubber bung back their position.

now.

To the level of water in the tank whon adding water.

Invalid water in the tank should not go over the "MAX" indicator on the scale at time. When humfelding 'dusing the cod function) the level of water in the tank uid not go below the "MM" indicator on the scale at any time.

To so a flactor in Early (only lang to boos set if all me are recommended) into the top one of the scale of the



- ONOFF Butten: After connecting the power cord the air cooler is in standay mode. Press the power covid flustion to laim the air cooler on or off.

 SPEED Button: Press the Speed button to cycle through the fan speeds. The currently selected fan speed will be illuminated on the display.
- A Low Speed
- N High Speed

- 36 Breeze: The fan speed will fluctuate between speeds to imitate a natural in
- Sleep: The fan speed will decrease by one level per half hour and then continue to run at Low Speed.

USE OF REMOTE CONTROL: Insert batteries (2 x AAA not supplied). There are 7 buttons on the remote control. They have the same function as the control panel. Point the remote control at the unit to operate. The effective distance is up to 6 meters. When the remote control is not in use store safely and

WARNING: Ensure that the fan is switched off from the mains supply and unplugged before attempting to clean any part of the unit.

We recommend changing the water on a daily basis to help keep the paper evaporator water filter and tank clean and free from odours.



www.mylek.co.uk

https://drive.google.com/drive/search?q=MY19RC